SMD REMOVAL

[With solder iron or warm air bath]

- Apply flux to all leads with syringe.
- Melt CHIP QUIK® uniformly on all pins.
- Maintain alloy in molten state long enough to release chip.
- Lift chip from board with dental pick.

CLEAN UP

- While molten, use a cotton swab and flux to move excess to an unused section of board. Let solidify and remove excess.
- While applying heat, polish each pad with a swab and flux until thoroughly clean.
- At room temperature clean residue with alcohol pad.
- You are now ready to install the new chip.

2.5 ft. CHIP QUIK® material, removes 1250 to 1500 SMD pins.

PATENT #5,326,016

CHIP QUIK, INC.
FRAMINGHAM, MA 01701
1-800-836-2447 Tech Line
www.chipquikinc.com